



Manufacturing Attractive Bird Products

71024 Co. Rd. 13 Nappanee, IN 46550 • Toll Free (866) 546-0423
(574) 773-4975 • FAX (574) 773-7282

Sunset Inn Mounting Plate

- STEP 1: Position the martin house upside down on two cardboard boxes 14" apart. The roof peak is between the two boxes.*
- STEP 2: Center mounting plate on the bottom side of the martin house. There are 8 predrilled holes for mounting the plate to the martin house. Important: The center holes in the mounting plate are spaced so the bolt hole will be drilled through the bottom and through the divider inside the martin house. Turn the plate so the center holes will line up with the inside divider.*
- STEP 3: Predrill the bolt holes, using 13/64" drill bit, through the bottom of the martin house.*
- STEP 4: Fasten the mounting plate to the martin house using the 5/8" bolt with flat washer and lock nut. The flat washer should be used inside the martin house.*
- STEP 5: If the telescoping pole diameter is smaller than the mounting plate, wrap the pole with electrical tape. Wrapping the pole will keep the martin house from being wobbly.*
- STEP 6: Insert the top end of the pole into the mounting plate.*
- STEP 7: Predrill holes through the pole using 13/64" drill bit.*
- STEP 8: Fasten the mounting plate, martin house included, to the pole using 2" bolts and lock nuts. Caution: Make sure all the nuts and bolts are securely tightened before raising the martin house.*