



Manufacturing Attractive Bird Products

71024 Co. Rd. 13 Nappanee, IN 46550 • Toll Free (866) 546-0423
(574) 773-4975 • FAX (574) 773-7282

Trendsetter 18, 26 and 28 compartment ground stake

Dig a square hole 16" wide, 16" long and 30" deep. The painted end which has angle welded to the side is to be above ground. The welded clip at the opposite end, is for shipping, and will be in the cement at the bottom of your hole. Standing the ground stake in the center of your hole, fill the hole with wet premixed cement to ground level. Be sure the ground stake is plumb and leave 24" above the cement. Also fill the inside of the ground stake with cement, to prevent water from accumulating and freezing inside. The pole will slide over the ground stake later, so be sure to wipe clean the ground stake of any excess cement. The dimensions above require seven 80 lb bags of dry cement mix available at your local building store.