



Manufacturing Attractive Bird Products

71024 Co. Rd. 13 Nappanee, IN 46550 • Toll Free (866) 546-0423
(574) 773-4975 • FAX (574) 773-7282

Fountain of Success on 3" pole with Winch Add-On

SAFETY INSTRUCTIONS: Read and understand all of the instructions and cautions prior to the assembly and installation of the gourd system. Assemble and install gourd system only to the following instructions as improper installation could result in damage or serious injury.

LOCATION Your gourd system should be as far away from trees as possible. An average minimum distance of 40 feet away from trees is required. Martins like wide open flight paths around their housing. Think of your martin housing being an airport and the martin as the airplane. Martins prefer to have two or more runways to land and take off. Also, martin housing should be no closer than 25 feet or no further than 120 feet from human housing. Martins like to be close to people.

STEP 1: Using a post hole digger, dig a hole 36" deep by 9" diameter. Depending on your soil conditions, a large diameter hole may be needed. Remove the 2-1/2" square steel ground stake from the aluminum pole. The painted end with a piece of welded angle along the side is the end which is to be above ground. The welded clip at the opposite end will be at the bottom of hole. The welded clip is for shipping purposes. Stand the ground stake in the center of your hole. Fill the hole with wet premixed cement to ground level. Be sure the ground stake is plumb and leave 21" above the cement. Also fill the inside of the ground stake with cement, to prevent water from accumulating and freezing inside. The pole will slide over the ground stake later, so be sure to wipe clean the ground stake of any excess cement. The dimensions above require 2 bags of dry cement mix available at your local building store.

STEP 2: Bottom section of pole is 67" long with no holes. Middle section is 70-1/2" long with no holes. Top section is 70-1/2" long with holes at one end. Slide the splice support of the middle section (section 70-1/2" with no holes) into either end of the bottom section. Slide the splice support of the top section (section 70-1/2" with holes at one end) into the middle section. The three sections are held together by friction and gravity once erected.

STEP 3: Cut the cable tie and insert the end of the cable, which has a loop, into the slot located at the top end of the pole.

STEP 4: Insert the 6" aluminum pulley into the slot making sure your cable will be on the top end of the pulley.


STEP 5: Attach the 6" pulley to the pole by inserting the 3/8" x 5" bolt through the pole and pulley. Secure with 3/8" locknut.

STEP 6: Slide both perch rods into the top two holes in the pole. Center both rods and secure with two 1/4" set screws and allen wrench included with the hardware.




STEP 7: Insert the black cap into the top end of the pole. The cap is held in place by friction. You may need to gently tap the cap using a hammer. The black cap is important to keep water from filling the inside of the pole.

STEP 8: Place a stop bolt which is 1/4 x 3-3/4" into the remaining hole and secure with 1/4" flange nut.




STEP 9: Orient the hub (assembly that slides up and down the pole) so that the 1/2" hole located at the top is in the same corner as the end of the cable with loop. Insert the bottom end of the pole into the top end of the hub and slide the hub upward on the pole.




STEP 10: Insert the quick link found in your hardware bag into the 1/2" hole and attach the cable loop. Close the quick link and tighten with wrench.

STEP 11: Attach the winch to the bottom end of the pole at your desired height using two aluminum u-channel and 1/4 x 5-1/2" bolts and flange nuts. The cable is to extend straight down at the corner of the pole and should not be twisted around the pole. The u-channel has a V notch and the corner of the pole will fit into the notch. When mounted the winch is on the corner of the pole.



STEP 12: Attach the cable guide pulley approximately 10" above the winch using one aluminum u-channel and 1/4 x 5-1/2" bolts and flange nuts. The u-channel has a V notch and the corner of the pole will fit into the notch.



STEP 12: Thread the winch handle onto the winch. Slide the spring onto the winch beside the handle. Secure the spring with the 3/4" wide nut. (See picture on left)



STEP 13: Your gourd system is now ready to be erected. The lower you keep the hub on the pole when erecting, the easier it is to balance. Obtain assistance when erecting as working with objects above your head can cause serious injury. Set the gourd system, with pole, vertically over the ground stake and slide the pole down to ground level

STEP 14: Attach the gourd arms to the hub. The gourd will slide onto the end of the arm with a small hole drilled in it. Insert the opposite end (end with flat sides) into the arm bracket. The system is designed to have 4 gourds on the top row and 8 gourds on the bottom row. The 4 arms for the top row are 2" shorter in length. The 8 arms for the bottom row are the longer arms and will have a slight bend located at the end where the arms have flat sides. Insert the flat end into the brackets. Orient the arm so that it will slide into the flat holes in the bracket.



STEP 15: Vertically hung gourds may require their hanging holes to be enlarged to 3/8". Slide the gourd onto the arm and insert a hitch pin into the small hole, at the end of the arm, to keep the gourd from sliding off.

STEP 16: Turn the winch handle to raise and lower your gourd rack. The stop bolt will stop the rack once the rack reaches the top of the pole. **DO NOT OVERTIGHTEN THE CABLE OR DAMAGE MAY OCCUR.**

CARING FOR YOUR GOURD SYSTEM: Oil the pulleys once a year to keep them working smoothly. It is recommended waxing the aluminum pole once a year with car wax. Remove the nest and clean the gourds at the end of each season. It is highly recommended to store the complete system inside for winter storage. Check all the bolts to make sure they are all tight before putting the system up each spring.

d lower your gourd rack. The stop bolt will stop the rack once it reaches the top.

